

Introduction	
Product Feature List	3
Important Notes	3
Load Limits	
Temperature Limits	3
Scheduling Considerations	3
Installation	4
Basic Operation	4
Understanding the Menu System	4
Menu Selection Point	
Action Selection Point	4
How to make a selection	5
Success LED feedback	5
Yellow Menu (Delay Timer Function)	6
Purple Menu (Load Type)	6
Blue Menu (Network Profile)	7
Standard Features	7
Operating the Local Load	8
Joining a Z-Wave Network	8
Network Wide Inclusion	8
Manual Inclusion	8
Leaving a Z-Wave Network	9
Associating to a Z-Wave Controller	9
Removing an Association from a Z-Wave Controller	9
Additional Features	10
Operating Remote Devices	10
Peer Association	10
Assisted Association	10
Removing Associations	11
Transmit Device Information	
Reset Default Settings	
Hardware Reset	
Programmable Delay Functions	11
Load Type Detection	12
Wireless Information	12
About Z-Wave	13
Device Types	13
Controller Types	13
Network Center (SIS)	13
Slave Types	13
Inclusion, Association and Exclusion	13
Inclusion	13
Association	14
Exclusion	14
Interoperability and Certification	14
Supported Z-Wave Command Classes	14
Controlled Z-Wave Command Classes	14
Troubleshooting	15
Dimmer Problem	15
Switch Problem	16



Specifications	. 1
Technical Assistance	
Limited Warranty	



Introduction

Congratulations on your new **QEES RETO Plug-in**.

You can now wirelessly control your appliances or lighting equipment while metering their power consumption.

All **QEES** Z-Wave® products are Z-Wave-certified. This ensures interoperability with Z-Wave-certified products from other manufacturers.

Product Feature List

Soft fade ON/OFF (dimmer products)
Timed Dimmer Function (dimmer products)
Multi-Color LED
Wireless Control

Important Notes

Install in accordance with all appropriate electrical codes and regulations.

If you are unsure about any part of these instructions, consult a qualified electrician.

CAUTION: The device should not be used for the control of high power heating appliances such as portable heaters. The device should not be used to control lighting that is used with electronic low-voltage and high frequency power supply transformers, nor high pressure discharge lamps (HID lighting) unless they are explicitly marked as dimmable/compatible with dimmers. This includes mercury-vapor, sodium vapor and metal halide lamps.

Unplug the device when servicing connected lighting fixtures.

It is normal for the device to feel warm to the touch during operation.

Clean the device with a soft damp cloth only. Do not use any chemical cleaners.

NOTE: When connected to mains power, your device will turn itself ON for two seconds and then turn OFF again. This is expected behavior, your device is determining the type of load it has been connected to and will then turn OFF for safety.

Load Limits

Max. 13A, 3.68 KW/240 VAC - 1.6 KW/110 VAC

Max. 1,66A, Resistive 400W/240 VAC – 190W/110 VAC (dimmer products)

Temperature Limits

Operating Temperature: -20 Celsius to +50 Celsius

Scheduling Considerations

Remember to exercise good common sense and prudence when using the timer and scheduling features of the device, especially when using them with unattended devices. There can be some unexpected consequences if not used with care. For example, an empty coffee pot can be turned on remotely. If that should happen, the



coffee pot could be damaged from overheating. If an electric heater is turned on by remote control while clothing is draped over it, a fire could result.

Installation

Step 1.

If the connected appliance has a separate switch or on/off button, please make sure that it is switched on.

Step 2.

Plug the appliance to be controlled into your **QEES** RETO Plug-in.

Note: **QEES** RETO Plug-in Dimmer is to be connected only to dimmable loads.

Step 3.

Plug your **QEES** RETO Plug-in into an existing wall socket outlet. It will start lighting blue while it searches for a Z-Wave network.

Basic Operation

Understanding the Menu System

QEES devices use a menu system to make operating their functions easy and intuitive. Color-coded menus provide a clear indication of the functions they make available, allowing you to operate your device with simplicity, instead of forcing you to memorize convoluted combinations of button-press patterns.

There are four main points you need to focus on:

- 1. How to make the selection;
- 2. The Menu Selection Point;
- 3. The Action Selection Point:
- 4. Success LED Feedback.

1. How to make a selection

Menu Selection – once you have decided on a menu click on the Plug-in and hold the button in order to select it. While you keep the button pressed the LED will switch off and will flash the menu color and show the first action color (usually cyan).

Action Selection – you need to press and hold the button once you reached the option you decided upon (remember you need to be inside a menu for this to happen). As you hold the button pressed the LED will turn off and the device will start performing the selected action, along with the relevant feedback for it.

2. Menu Selection Point

To get to the menu selection point you need to press four times on your QEES Plugin. You know that you have reached the menu selection point if you see white LED



feedback. Here you can cycle through all the menu options by clicking on your QEES Plug-in (note: each click will show a different color representing a different menu):

- 1. Yellow Delay Timer Profile;
- 2. Purple Load Type Profile;
- 3. Blue Network Profile;
- 4. Red Go Back to Main Menu this option takes you out of the menu selection point.

3. Action Selection Point

You have decided on a certain menu and selected it as described above. Once you have selected the menu you enter the Action Selection Point. You can now cycle through different action options by clicking on the **QEES** Plug-in. Each action option has a specific LED feedback as described below:

Example: Blue Menu

- 1. Wait for remote association blue flash followed by cyan color
- 2. Enter Z-Wave learn mode blue flash followed by yellow color
- 3. Restore default settings blue flash followed by purple color
- 4. Go Back to the Menu Selection Point action illustrated by a blue flash and red color

4. Success LED Feedback

The success LED feedback is most of the time Green.

The feedback LED is as follows:

Nr.				LED
Crt.	Menu	Action	LED Action	Color
1		Delay Timer 15 min	1 glow	green
2		Delay Timer 30 min	2 glows	green
3	Yellow	Delay Timer 45 min	3 glows	green
4	WO	Delay Timer 60 min	4 glows	green
			depends on what you selected	
5		Delay Timer Status	from the options above	green
6		Check Load	1 glow	green
7.1	Purple	Load Type (Incandescent)	1 glow	green
7.2	le	Load Type (LED, CFL)	1 glow	green
8	Blue	Wait for incomming association	1 glow	green
9	ue	Classical Z-Wave learn mode	Glow	blue



		Reset to factory		
10		default	1 glow	green
11		Toggle local load	1 glow	green
	7	Toggle all remote		
12	Main Menu	loads associated	1 glow	green
	n N	Attempt to join a		
13.1	1en	network	Glow	blue
13.2	้น	Send NIF	Glow	purple
14		Menu Selection Point	Glow	white

Yellow Menu (Delayed Timer)

Your **QEES** RETO Plug-in device comes equipped with a **Delayed Timer Function**. If this feature is activated while your **QEES** dimmer's load is turned on, it will slowly dim down the load from its current level to off state over a certain amount of minutes.

To activate the **Delayed Timer Function** on your **QEES** dimmer, you need to get into the Yellow Menu (as described above) and select the amount of minutes you want the dimming action to be performed in. The default time span is 15 minutes. Once you activate this option the load connected to the device will be turned on (if is not on already).

The Action Selection Point in this menu consists of different amount of minutes you can program your dimmer to dim down the load to off state.

The actions (that you cycle through by a single click on the Plug-in button) and LED feedback associations in the **Yellow Menu** are:

- 1. **Cyan** 15 minutes
- 2. **Yellow** -30 minutes
- 3. **Purple** 45 minutes
- 4. **Green** 60 minutes
- 5. **Blue** timer status (one green glow for 15 minutes, two green glows for 30 minutes, three green glows for 45 minutes, four green glows for 60 minutes)
- 6. **Red** get back to Menu Selection Point

The same action performed on a Plug-in Switch will turn off the load in the amount of minutes that you selected.

Purple Menu (Load Type)

Every single version of **QEES** Plus devices come with a Load Type menu. In this menu you can check the load to see if it works or not and you can detect the load type (LED, CFL, Incandescent etc.).

To activate the Purple Menu go to menu selection point then click your way to the purple option. Then click and hold the button pressed until the LED turns off and



starts to glow purple and show a different color (the action color – usually cyan for the first action from the specific menu).

The actions (that you cycle through by a single click on the Plug-in button) and LED feedback associations in the **Purple Menu** are:

- 1. **Cyan** Report load status (shows load status of device and gives you information about the load if it is either LED, CFL or Incandescent)
- 2. **Yellow** Recheck (automatically set load type)
- 3. **Purple** Set as incandescent
- 4. **Green** Set as CFL and/or LED
- 5. **Red** Menu exit.

Blue Menu (Network Profile)

In this menu you can perform network connectivity actions. When you want to include/exclude the device to/from your network you go to this menu and select the action that you need.

To **activate** the **Blue Menu** go to menu selection point then click your way to the blue option. Then click and hold the button pressed until the LED turns off and starts to glow blue and show a different color (the action color – usually cyan for the first action from a specific menu).

The actions (that you cycle through by a single click on the Plug-in button) and LED feedback associations in the **Blue Menu** are:

- 1. **Cyan** Wait for incoming Remote Association (the remote device sends a NIF node information frame and the device receives it);
- 2. **Yellow** Enter Z-Wave Learn mode (the device looks for Z-Wave controller that is in inclusion mode and joins their network or if already in a network will start the exclusion process);
- 3. **Purple** Factory defaults (the same settings the device had when was shipped from our factory);
- 4. **Red** Menu exit.

Standard Features

Operating the Local Load

Loads that are directly plugged into the device can be controlled from the **Main Menu**. Double pressing your **QEES** device's Plug-in will trigger a toggle of the connected load's state. This means that if the load is OFF and you double press the Plug-in while on the Main Menu, your **QEES** device will turn the connected load ON. Double pressing it again will turn the connected load OFF. You can operate the local load even if your device is not included in a Z-Wave Network.



Joining a Z-Wave Network

QEES Z-Wave products support two different methods of joining Z-Wave Networks. Relatively recent Z-Wave controllers support **Network Wide Inclusion** which makes including Z-Wave devices simple. Older controllers might not support this feature.

QEES MyKey (controller) supports both modes and will by default try to include devices into the Z-Wave Network using **Network Wide Inclusion** first. If you are using a different Z-Wave controller, please refer to its user manual for inclusion instructions.

1. Network Wide Inclusion

All **QEES** Z-Wave devices that are not part of a Z-Wave Network will enter "Network Wide Inclusion" mode when powered up. While in this mode, the device will light its LED blue, indicating that it is waiting for a Z-Wave controller to include it into its Z-Wave Network. At this point you can initiate the **Network Wide Inclusion** process on your Z-Wave controller.

You can stop the inclusion process at any time by pressing the device button. The process times out after a minute of waiting to be included in a Z-Wave Network. At this point your **QEES** device may be operated locally only. Once your **QEES** device is found and added to the Z-Wave Network by a controller, it will light green indicating a successful inclusion.

To manually put your slave device in Network Wide Inclusion mode press three times on its shell. While in this mode, the device will light its LED blue, indicating that it is waiting for a Z-Wave controller to include it into its Z-Wave Network. If your device is already included in a Z-Wave Network pressing three times on its shell will broadcast a **Z-Wave Node Information Frame** instead.

2. Manual Inclusion

If you have an older Z-Wave controller, or one that does not support Network Wide Inclusion, you can use **Manual Inclusion** to include your device in a Z-Wave Network.

Instead of triple pressing your device, navigate to the **Blue Menu**.

Once in the **Blue Menu**, enter **Z-Wave Learn Mode** by selecting the yellow option (the LED feedback for this action as described above). Your Z-Wave controller should now be able to include your **QEES** device while its LED is flashing blue.

NOTE: Some Z-Wave controllers will not include your **QEES** device unless they are also put in **Z-Wave Inclusion Mode**. For this please refer to the controller's user manual.

Leaving a Z-Wave Network

There will be times when you will want to remove your **QEES** device from its current Z-Wave network. Regardless of the process used to include it, the process for removing it from its current network is always the same.



Your Z-Wave controller will need to be put in **Exclude from Z-Wave Network** mode. Refer to your controller's manual for instructions on how to perform this action.

With your Z-Wave controller in **Exclude from Z-Wave Network** mode navigate to the **Blue Menu** on the **QEES** RETO Plug-in you want to remove from the network. Once in the **Blue Menu**, select the exclusion process by choosing the yellow feedback. The yellow feedback in the **Blue Menu** will cause your **QEES** device to go into **Z-Wave Learn Mode**.

Your **QEES** RETO Plug-in's LED will flash blue while the request is being processed by the Z-Wave controller. Once it has been removed from the Z-Wave network, it will flash the LED green. You will need to include your **QEES** device in a new Z-Wave network before it can be remotely controlled.

Associating to a Z-Wave Controller

Once your **QEES** RETO Plug-in is part of a Z-Wave Network, you can create *associations* between devices. Associations allow you to operate the device remotely using Z-Wave controllers or other devices in your Z-Wave Network. Your **QEES** device needs to be part of the same Z-Wave network your controller is in, before you can create any association to it.

Different Z-Wave controllers have different ways of initiating the Z-Wave association process. Please refer to your controller's manual for instructions on how to create an association.

You will be asked to broadcast a **Z-Wave Node Information Frame** (NIF) from the device you wish to create an association to. On **QEES** RETO Plug-in products this is accomplished by pressing three times on the button. Your **QEES** device will flash its LED purple while it transmits the NIF. Your Z-Wave controller will provide you with feedback on whether the association was successful or not. You can now control your **QEES** device from your Z-Wave controller.

Removing an Association from a Z-Wave Controller

Sometimes you will want to remove an association from your Z-Wave controller to a **QEES** device. This process will only remove an association from the Z-Wave controller and will not remove your **QEES** device from the Z-Wave network or affect any other associations to it.

Please refer to your Z-Wave controller's manual for instructions on how to remove associations from it. Associations are typically made to and removed from "groups." This means that it is possible to have various associations to the same device on different groups on the same controller.

The "group" term is to be understood here as button.

You will be asked to broadcast a **Z-Wave Node Information Frame** (NIF) from the device you wish to remove the association to. On **QEES** RETO Plug-in products, this is accomplished by pressing three times on the button. Your **QEES** device will flash



its LED purple while it transmits the NIF. Your Z-Wave controller will provide you with feedback on whether the association was successfully removed or not.

Additional Features

Operating Remote Devices

Even though **QEES** RETO Plug-in is not a Z-Wave controller, it can still control other Z-Wave devices that are in the same network. Devices that are associated to your **QEES** product will be controlled, along with the locally connected load, by single pressing the device while in the **Main Menu**. If the remote devices that are associated to the **QEES** RETO Plug-in are dimmers, you can dim them up or down by holding down the press in the **Main Menu**. This action will not affect to local load, unless the **QEES** device you are operating is also a dimmer.

Before you can control remote devices from your **QEES** product, you must associate them to it. If the device you want to control is in direct range with your **QEES** device, **Peer Association** is the easiest way to perform the association. If the two devices are not in direct range you will have to perform an **Assisted Association**, which requires your Z-Wave controller.

Peer Association

If both your devices are directly in range of each other, **Peer Association** is the fastest and easiest way to create an association between them. Navigate to the **Blue Menu** on your **QEES** RETO Plug-in. Once in the **Blue Menu**, select "**Wait for incoming Association**" action by choosing the cyan option. Your **QEES** device will flash its LEDs blue while it waits for a device to create an association to.

While your **QEES** RETO Plug-in is flashing blue, transmit a **Z-Wave Node Information Frame** (NIF) from the device you want to control. If this second device is also a **QEES** device, this is accomplished by pressing it three times. Your **QEES** device will flash its LEDs purple while it transmits the NIF. Refer to your device's manual for instructions on how to transmit a NIF if you're not using a **QEES** product.

Your **QEES** RETO Plug-in will indicate that the association was successful by flashing its LED green. You can now control the remote device by pressing once on your **QEES** RETO Plug-in while in the **Main Menu**. If your **QEES** device does not seem to receive the NIF from the product you want to control, they might not be in direct range and the association between them must be created using **Assisted Association**.

Assisted Association

Just because two devices are far away from each other does not mean they cannot communicate with each other. Using the routing capabilities of the Z-Wave network you can control devices from your **QEES** product that are beyond its direct range. The association process, however, requires the devices to be in direct range so you will need to use your Z-Wave controller as a middle man. This procedure is known as Assisted Association.

Please refer to your Z-Wave controller's manual for instructions on how to perform **Assisted** (also called **Signed**) **Associations**. You will be asked to transmit a Z-Wave



Node Information Frame (NIF) first from the *target* device (the one you want to control) and then from the *source* device (the one you want to control with). Transmitting a NIF is accomplished by pressing three times on your **QEES** RETO Plug-in. Your **QEES** device will flash its LED purple while it transmits the NIF. Your Z-Wave controller will provide you with feedback on whether the association was successful or not.

Removing Association

You can remove existing associations on your **QEES** RETO Plug-in by simply repeating the steps made to create an association. Your **QEES** device will see the request to duplicate an already existing association and will remove it instead.

Transmit Device Information

Various operations with Z-Wave devices will require you to transmit a special type of information message from your **QEES** device. This message is known as the **Z-Wave Node Information Frame** (NIF) and contains information about your device, the features it provides, the functionality it supports and its network status.

Once your **QEES** RETO Plug-in is part of a Z-Wave network all you need in order to transmit a NIF is to press it three times. Your **QEES** device will flash purple while it transmits the NIF.

Power Metering

Your **QEES** RETO Plug-in meters the energy consumption of its locally connected load at all times. Other Z-Wave devices that support the functionality can query your **QEES** device for this data. Please refer to your device's manual or guide for instructions on how to query Z-Wave devices for power metering data.

All **QEES** Z-Wave devices use a default scale of "0" for Z-Wave power metering purposes.

Reset Default Settings

You can easily restore the settings of your **QEES** RETO Plug-in to the same conditions it had when it was shipped from our factory. To restore default settings on your **QEES** device, first navigate to the **Blue Menu**. Once in the **Blue Menu**, select the purple option.

Hardware Reset

Should your **QEES** RETO Plug-in ever stop responding or begin to behave erratically you can reset its internal hardware. You do this by pressing your **QEES** RETO Plug-in and keep it pressed down. Keep the device pressed down for at least 40 seconds. This will trigger the reset circuitry of the device and restart it.

Programmable Delay Functions

Your **QEES** RETO Plug-in dimmer comes equipped with a **Delayed Dimmer** function. If this feature is activated **QEES** dimmer will slowly dim down the load from its current dim level to off level over a certain amount of minutes. If the load is OFF then this action will turn it ON.



To activate the **Delayed Dimmer** function on your **QEES** dimmer, press it three times and hold down the last press, while in the **Main Menu**. Your **QEES** RETO Plug-in will flash its LED green, confirming the start of the **Delayed Dimmer** function. At this point, the device will begin to dim the load to off level over the same amount of minutes as it did the last time the feature was activated, or over the amount of minutes that were configured in the features setup. The default time span is 15 minutes.

You can find out what the **Delayed Dimmer** function's current countdown is set for, as well as modify it for the next time it is activated, from the **Yellow Menu**. Once in the **Yellow Menu**, selecting the blue option will trigger the action "Timer Status". One glow means the function is set for 15 minutes. Two glows means the function is set for 30 minutes. Three glows means the function is set for 45 minutes. Four glows means the function is set for 60 minutes.

The same function is available for the **QEES** RETO Plug-in switch with the difference that the load will not dim but will directly switch off in the amount of time that you previously set.

Load Type Detection

Your **QEES** RETO Plug-in will attempt to automatically detect the type of connected load when it is powered up. This allows your **QEES** device to configure itself to treat the connected appliance in the best possible way. You can find out what load your **QEES** device is connected to from the **Purple Menu**. To navigate to the **Purple Menu** press four times to reach Menu Selection Point and cycle by clicking on the device to the purple option. Select the purple option and reach the Action Selection Point. To activate the "Load Detection" action you need to select the yellow option:

LED Lights **Green [1 flash]**: Incandescent Bulb

LED Lights Green [2 flashes]: Compact Fluorescent Lamp (CFL) Bulb

LED Lights Green [2 flashes]: Light-Emitting Diode (LED) Bulb

You can also force your **QEES** device to re-detect the connected load from the **Purple Menu**. For this action please select the Cyan option.

Wireless Information

About Z-Wave

Z-Wave is a next-generation wireless ecosystem that lets all your home electronics talk to each other, and to you, via remote control. It uses simple, reliable, low-power radio waves that easily travel through walls, floors and cabinets. Z-Wave control can be added to almost any electronic device in your house, even devices that you would not ordinarily think of as "intelligent," such as window shades, thermostats and home lighting.

Z-Wave unifies all your home electronics into an integrated wireless network, with no complicated programming and no new cables to run. Any Z-Wave enabled device can be effortlessly added to this network, and many non-Z-Wave devices can be made compatible by simply plugging them into a Z-Wave accessory module. In seconds, your device gets joined to the network and can communicate wirelessly with other Z-Wave modules and controllers.



Z-Wave delivers on all the promises of the wired home, and opens up exciting new possibilities for the home of the future.

Device Types

Controller Types

A Z-Wave controller is a device that can build a Z-Wave network. Controllers can be either portable, battery powered or they can be static (located at a fixed position like an in-wall relay) and mains powered. **QEES** MyKey is an example of a portable controller. The first controller you use when you build your Z-Wave network is your primary controller, meaning that this is the controller you **MUST** use to add new devices to the Z-Wave network in the future. Unless you have a network center (see below) in your network, no other controllers can be used to add new devices to the network. All other controllers in the network behave like secondary controllers (they can still be used to control all devices in your home and to set up associations in your network). If a network center is present all controllers behave as primary controllers and can add new devices to the network. A Z-Wave controller is required to create a Z-Wave network.

Network Center (SIS)

Static controllers can be configured to take care of all network maintenance. In this case the device is the network center (SIS controller) and MUST be switched on at all times. QEES RETO Plug-in devices are capable of being network centers. Note that there can only be one network center in your network and this center should be included to your network as the first device. When a network center is present, all Z-Wave controllers behave as primary controllers and all can be used to add new Z-Wave devices to the network.

Slave Types

Slave devices are not capable of building a network (include and exclude devices). They can only send/receive operation commands to/from devices and react to them (e.g. on/off, dim up/down). **QEES** slave devices are typically one or two button devices, such as your **QEES** RETO Plug-in.

Inclusion, Association and Exclusion

Inclusion

Inclusion is the process of adding a new Z-Wave wireless device to your Z-Wave network. After inclusion the new device can "talk" to all other devices in the network (control them and/or be controlled by them). Also, mains powered devices can be used as repeaters in your Z-Wave network – in this way routing is used to extend the range of the network. When including a new device to your Z-Wave network, the primary controller must be ready to add a new device and the new device must tell the controller that it wants to be included. If your **QEES** RETO Plug-in is not already added to a network, it will request to be added when powered up or when pressing its button three times. Your Z-Wave controller must be ready to add the device for the operation to be completed successfully.



Association

Association is the process of setting up a wireless link between two or more devices. By setting up an association to another Z-Wave device on your QEES RETO Shell you can control both the locally connected load and the remote device, wirelessly. It is possible to set up associations to/from any QEES Z-Wave device. For all QEES devices, associations can be set up from any Z-Wave controller that supports the Association Command Class. The process of setting up associations in this way should be described in your Z-Wave controller's manual. Setting up an association between two devices in the same network is also possible for QEES Z-Wave devices without having to use a controller, so long as they are in direct range. You must first navigate to your QEES RETO Shell's Blue Menu. After reaching the Blue Menu you have to select the yellow option in order to get the device ready for association by putting it in Z-Wave Learn Mode.

Exclusion

Exclusion is the opposite of inclusion and is the process of removing a Z-Wave device from a Z-Wave network. Once a device has been excluded, no other device in the Z-Wave network can control or be controlled by it. All associations to the device should be manually removed before exclusion. A device can be excluded from the network by any controller. To exclude your **QEES** RETO Plug-in you must first navigate to the **Blue Menu**. Here you need to select the yellow option for "Z-Wave Learn Mode". The device will flash blue and is now ready to be excluded from the Z-Wave network. Notice that a Z-Wave controller must also be in exclusion mode for the process to complete successfully.

Interoperability and Certification

All **QEES** Z-Wave devices are Z-Wave Certified. This guarantees that **QEES** Z-Wave devices will be interoperable in a network with other third party Z-Wave Certified devices.

Supported Z-Wave Command Classes

Basic Command Class
Binary Switch Command Class
Multi Level Switch Command Class Version 2 (dimmers)
All Switch Command Class
Association Command Class Version 2
Manufacturer Specific Command Class Version 2
Version Command Class
Meter Command Class Version 3
Firmware Update Meta Data Command Class
Scene Actuator Configuration Command Class
Scene Activation Command Class

Controlled Z-Wave Command Classes

Basic Command Class Multi Level Switch Command Class Version 2



Troubleshooting

Dimmer Problem	Possible Cause	Solution
The QEES device is not	The load is not properly	Try checking if the wiring
providing any feedback.	installed.	was made according to
		manual instructions.
	Light bulb is burned out.	Try changing the bulb with
		a new one.
Cannot add the device to a	The device is too far from	Try moving closer to the
network	the Z-Wave repeater.	repeater.
	The device is already	Try to exclude or perform
	included.	reset to default settings.
	The type of load is not	Make sure that the lamp
The QEES Dimmer light	dimmable	you are using is a
flickers, especially at low		dimmable or incandescent
dimming levels.	The lead has a goted passes	lamp
	The load has a rated power of more than 70-100 W	Try using less powerful lamps.
My LED lamp appears to	This is normal. Some	Please note that the
have very low active	types of LED lamps are	maximum ratings of the
power consumption, but it	highly reactive loads and	QEES devices are for a
draws a significant amount	mostly draw reactive	power factor of no less
of current.	power, not active power.	than 0.85.
	F	
I am trying to dim my	Some types of LED lamps	In consequence the load on
LED lamp, but it does not	contain special circuitry	this type of LED lamps
seem to respond at all, or it	which stabilizes its input	can not be dimmed. Make
responds erratically.	voltage.	sure the lamp you are
		trying to use is marked as
		dimmable.
As soon as I start dimming	The load you are trying to	As a measure of
the load upwards, the level	power is trying to draw too	precaution, the dimmer
abruptly falls down to 0	large a current.	will immediately turn the load off, as attempting to
and I am getting a warning feedback from the device.		dim such a load can
recuback from the device.		damage it irreversibly.
		Please check the load you
		are trying to dim. Also,
		please remember that the
		dimmer is <i>not</i> intended to
		be used with anything but
		lighting appliances. Using
		it with heavily reactive or
		non-linear loads, such as
		vacuum cleaners,
		computer power supplies
		or television sets can
		damage it irreversibly.
I om massing	The mass on the diam.	If the lost several 11 '
I am pressing on my	The press on the dimmer	If the last saved level is



dimmers button, but the device does not light up	button will cycle the load between level 0 and the last saved level.	very low, it may appear that the device is not working. Please hold the dimmers button to toggle it to a higher level.
The QEES Dimmer has locked up or is not responding		Please refer to the manual to reset the device.
I had my devices in a group and I manually adjusted the dimming level of one of them (or toggled one of the relays). Now they are out of sync.	accordance with Z-Wave	You can readjust the device manually (locally) until is back in sync.

Switch Problem	Possible Cause	Solution
My LED lamp appears to	This is normal. Some	Please note that the
have very low active	types of LED lamps are	maximum ratings of the
power consumption, but it	highly reactive loads and	QEES devices are for a
draws a significant amount	mostly draw reactive	power factor of no less
of current.	power, not active power.	than 0.85.
I cannot toggle my relay	The load you are trying to	As a measure of
anymore. It is constantly	power is trying to draw too	precaution, the relay locks
on and I am getting a	large a current.	in the On position, as
warning feedback from the		toggling it above the rated
device.		current can damage it
		irreversibly. Please
		disconnect the load
		manually, either by
		unplugging it or by
		toggling its power cycle
		button. You should be able
		to toggle your relay again.
The QEES Switch has		Please refer to the manual
locked up or is not		to reset the device.
responding		
I had my devices in a	This behavior is in	You can readjust the
group and I manually	accordance with Z-Wave	device manually (locally)
toggled one of the relays.	protocol.	until is back in sync.



Now they are out of sync.	

Specifications

QEES RETO Plug-in Switch

Supply Voltage: 100-240 VAC - 50-60 HZ

Standby power: 0,3W

Rated power: Maximum 16 A resistive load, 3680 W/230 VAC

Protection rating: IP 20 - Only for indoor use.

Power fuse: Max. 13 A

QEES RETO Plug-in Dimmer

Supply voltage: 100-240 VAC - 50-60 HZ

Standby power: 0,4W

Rated power: 400 W/230 VAC - 190W/110VAC Protection rating: IP 20 - Only for indoor use.

Power fuse: Max. 13 A

Technical Assistance

For questions concerning the installation or operation of this product, please call **QEES** Support Center.

EUROPE, USA, CANADA (24hrs/7days) (+40)316201275 support@qees.eu

Limited Warranty

QEES products come with one (1) year warranty starting with the date of purchase. During this period the all **QEES** products are free from manufacturing defects and comply with the specifications in the manual. The devices not complying with the above facts will be repaired, replaced or refunded by **QEES** only if the products have not been subject to faulty use, improper installation or abuse.

Defective products during warranty period have to be shipped along with dated proof of purchase to:

QEES A/S Kultorvet 9, kl. 1175 København K, Denmark

QEES is in no case liable for: (1) the improper, inappropriate or negligent use of the products by the Buyer or any third party; (2) the failure by the Buyer or any third



party to comply with **QEES**' instructions (whether oral or in writing) for the storage, location, installation, maintenance, use or operations of the products, or in the absence of instructions, according to the most common practice in the relevant field; (3) the use of products on unsuitable equipment or for a use not expressly authorised by **QEES**; (4) the failure by the Buyer or any third party to implement **QEES**' recommendations regarding the products; (5) any repair, adjustment, alteration or modification of products by the Buyer or any third party.