



EURO-version Quickguide





danalock installation:

current door lock	02
Pick and insert new cylinder	03
Power up the lock	04
Mounting the backplate on the door	05
Using the tailpiece extenders	06
Mounting your danalock to the backplate	07
Lock/unlock door with the User button	08
Inclusion mode	09

danalock App:

Download from App Store and Google Play	11
Create a user	12
Create user profile	13
Adding a new lock	14
Install new lock	15
Refresh key	16
Lock/Unlock	17
Sharing keys with others	18
Accessing lock settings	19

Lock settings	20
Auto unlock settings special for iOS	21
Activate Auto unlock on iOS	22
Auto unlock settings special for Android	23
Activate Auto unlock on Android	24
Re-activate Auto unlock	25
Knock to unlock	26
Knock to unlock add-ons	27






(*)


Remove the current door lock

■Index

First you have to remove your current door lock, including the thumb turn and cylinder. (a)

Remember to unscrew the lock-screw in the mortise-plate at the side of the door. (b)









Pick and insert new cylinder

In the danalock box you'll find 4 extra lock cylinders. Use the one that matches the cylinder you removed from your door.

Measure the back part (green on illustration) with your old cylinder.



You measure the lock from the middle of the screwhole and away from thumb turn.



danalock installation: Power up the lock




Release the lid

To power up your danalock circle you first have to remove the top lid from the housing base.

Use a small flathead screwdriver to separate the lid from the housing base.


Be gentle when removing the lid.



Power up the lock

The danalock comes with batteries inserted, but a thin plastic folio guarantee that your new danalock is fully charged. vRemove the folio and the danalock lits up with a green light for 5-10 seconds.

NOTE: This LED is the ONLY light that lits up, after the folio has been removed.





danalock installation: Mounting the backplate on the door



Release the baseplate

Now release the 3 screws that hold the baseplate.






Tailpiece the right size

To avoid damaging the danalock you will have to shorten the tailpiece.

The tailpice must extend maximum 15 mm from the baseplate.

This is important, if the tailpiece is longer it will damage the motor in the danalock.




danalock installation: Mounting your danalock to the backplate




Mounting your danalock to the backplate

Take the housing base and place it over the baseplate.

Make sure that the tailpiece fits the slide in the middle of the housing base.





Put the top lid back on.Take the top lid and gently press it back on the housing base.

danalock installation: Lock/unlock door with User button



Lock/unlock door with User button

The User/touch button gets activated when you hold your finger on it.

The user button has various purposes, and it's action depends on how long you press it.

Note: Depending on how your deadbolt is installed, to unlock your door manually you must turn the danalock the opposite direction. Read here for more about lock direction.



Lock door:

To lock the door place your finger on the user button for no more than 1 second.

Release the finger, and the danalock will start a lock session.

Unlock door:

To unlock the door place your finger on the user button between 1 and 3 seconds.

Release the finger, and the danalock will start a unlock session.

Manual lock/unlock:

You can lock or unlock your door by turning the danalock with the hand just like a thumb turn.

■Index

danalock installation: Inclusion mode

Inclusion mode:


In order to make your danalock connect to your smartphone, a gateway, if you want to reset the danalock to factory settings or delete all data on it, you need to put the danalock in inclusion mode.



Press the touch button in the middle of your danalock, and wait for the sound of 3 beeps. When you hear the 3 beeps, release the finger and the lock will sound a short counter beep, to confirm that the inclusion mode has been activated. (For establishing a connection between the smart phone and the danalock using bluetooth smart technology).



2 beeps release finger short confirm beep Press the touch button in the middle of your danalock, and wait for the sound of 2 beeps. When you hear the 2 beeps, release the finger and the lock will make a short counter beep to confirm that the inclusion mode has been activated. (For establishing a connection between the danalock and a gateway using z-wave).



5 beeps release finger short confirm beep Press the touch button in the middle of your danalock, and wait for the sound of 5 beeps. When you hear the 5 beeps, release the finger and the lock will make a short counter beep to confirm that the reset keys mode has been activated. (Now the stored encryption keys is deleted, and the memory of all the keys are gone).



Press the touch button in the middle of your danalock, and wait for the sound of 10 beeps. When you hear the 10th beep, release the finger and the lock will make a short counter beep to confirm that the factory reset mode has been activated. (Now all the custom made settings are deleted and the danalock's memory is reset to pay / default).

Factory resetting

Start with deleting the lock in the App. If this is the first time you read about the danalock App, <u>please read here.</u> Swipe from right to left, press the settings icon, and find the 'Delete your lock' button at the bottom of the page. <u>Read about deleting here.</u>



danalock App:



The danalock Application With the danalock App you can control your danalocks many features in detail, send key-invitations and much more.



MyLock App: Download from App Store and Google Play



Installing the danalock app on iOS

To install the Danalock App go to App Store or your smartphone.

Search for the app "Danalock".

Hit the download button to install the danalock app.

Technology is supported by iPhones from 45 - 45, 5, 55, 5C, 6. and iOS8

NOTE: When using iOS7 or older, be sure to desable location services when launching the Application.



Note: If you want to use the Auto unlock or Knock to unlock feature on you iphone, a warning will occur asking you to activate location services.

You will also have to activate Background updates, if you want to use Auto unlock and Knock to unlock with your phone. Do this in your iPhone settings under general by activating "Background Ann Refresh"

Installing the danalock app on Android

To install the Danalock App go o Google Store on your smartphone. Search for the app "Danalock".

Hit the download button to install the danalock app.

ndroid 4,4 or newer smartphones with Bluetooth Smart Technology




danalock App: Create a user



Create a user

After you have installed the Danalock app on your smartphone, please open it.

The first time you use the app you are asked to give your Phone a name



Enter a name and click "OK



The next page you will see is the Login Page. Before you can login to the system you will have to create a user

Click the link
"Create new user"



danalock App: Create user prpfile

Create user profile

You will be forwarded to the Create User Page.

The first 4 fields are mandatory:

Email: Write your email address. Make sure you enter a valid email address, as it is essential for resetting your password. It is also essential for future features.

Password: Your password can contain any character and musibe at least six characters long.

Confirm Password: This field must be exactly the same as the password field. It is used to verify that the password is not misspelled.

It is optional to fill ou the last 3 fields.



Scroll to the bottom of the page and press "Send".



You have now created a new user and are ready to login to the danalock application.

Now you can log in. This is how you start the application each time.



Fill in the Username and Password fields Press the Login button

You are now logged into the danalock app.

f it's the first time you log into the danalock App your next move will be to add a new lock to the application

danalock App: Adding a new lock


Adding a new lock

Open the main menu.

In the danalock App press the menu button on the top left corner to add a new danalock.

This will make the main menu swipe in from the left





Before you can add a new lock to the system you have to enable the Bluetooth Smart Include Mode.



In order to make a connection between your phone and your danalock, you have to press and nold your finger on the user button until you hear 3 beeps. Release the finger, and a short beep is heard. Now your danalock s in inclusion mode.



danalock App: Install new lock


Install new lock

Press "Add new lock". This will make the app start looking for any danalocks in the area.

First you need to go to your danlock on your door. Stand in front of the lock so the signal will be clear.




Choose your new lock. When the App finds your danalock it will be listed on the screen. Now press "Install"



Next step is to give your lock a name Press the arrow when you are done

A welcome screen opens up



Now you can configure your lock-settings in detail: Power-saving, turn-settings, battery-level and much more lead more here.


t is important that you save to the ock each time you make choice or a change. You can also choose to add your lock to the keychain and make your adjustments to the settines later

danalock App: Refresh key

Refresh key

If you want to access a danalock but can't find it in your Keychain in the App. or you don't have permission to use it it might help to refresh keys.

Press the menu icon in the top left corner, and press the "Refresh keys" button.



If that doesn't work please contact the owner of the danalock

Remember you have to be online to be able to refresh keys.

danalock App: Lock/Unlock

Lock/Unlock

To lock or unlock your door make sure that you are in bluetooth-range of the danalock.

If your danalock is in bluetooth-range it will look like this:





Lock door

Press the red padlock in you Keychain to lock the door.



When the Danalock locks, the LED on the lock will light up in red.



Unlock door

Press the green padlock to unlock the door.



When the Danalock Unlocks, the LED on the lock will light up green.



danalock App: Sharing keys with others

Sharing keys with others

To share access with others, you need to open the lock menu.



Do this by swiping the key from righ to left (using your finger).




Press the first icon



You now have to decide if you want to send a permanent or a temporary access to your home.



The key will be permanent if you dor insert dates in the calendar boxes.



If you write date and time in the calendar boxes, the key will only work in the period you specify. You can send your key-invitation as a SMS, email or via the danalock server.

The recipient will recive an e-mail from the Danalock team explaining what to do next.



danalock App: Accessing lock settings

Accessing lock settings

To change the lock settings. you need to swipe the key from right to left (using your finger)





Press the Lock Settings icon



Here you can change all the lock settings and check the battery status

Remember to save your changes on the lock by clicking on the buttor at the bottom.



Caution: This can not be undone!

You will be asked to verify your choise by writing "delete" befor continuing.



danalock App: Lock settings



Lock settings:

padlock symbol you

and modify the lock,



Important: Remember to save your changes when you have made

Lock settings:

Mode:

Direction: Here you can choose the

degrees:

Turn

Auto lock time: after you have unlocked

Lock settings:

Speed:

Sound:

Delete lock: Delete your lock if you want




danalock App: Auto unlock settings special for iOS





Auto unlock settings special for iOS

Note: If you want to Knock to unlock feature warning will occur asking you to activate



Remember to set Location to Always

TELMORE ♥		1
ALLOW ACCESS T	O LOCATION	4
Never		
While you use the a	арр	
Always		~
"Danalock uses loca: for Auto-unlock and		lock."

■Index

danalock App: Activate Auto unlock on iOS





Activate Auto unlock on iOS

Auto unlock is a nice feature that unlocks your door automatically when your

Stand in front of your danalock when you want to turn on the

If you are too far away from your lock you will get a warning. Move closer to the lock and try again.

Auto unlock works hest


if you hold the phone in your






















danalock App: Auto unlock settings special for Android



Note: If you want to use the Auto unlock or Knock to unlock feature on your android smartphone, you have to activate your phones location services.



This is done in the phones settings, press location.



Now switch location ON



et your phone to High accuracy.

danalock App: Activate Auto unlock on Android





Activate Auto unlock on Android

Stand in front of your danalock when you want to turn on the auto unlock feature

If you are too far away from your lock you will get a warning. Move closer to

Auto unlock works hest

if you hold the phone in your


















danalock App: Re-activate Auto unlock



Re-activate Auto unlock

If you have used the "Knock to unlock" feature you will have to manually switch back to auto unlock in the App settings.





danalock App: Knock to unlock








Knock to unlock

The Knock to unlock possibility to unlock your door by knocking lightly on your smartphone when

The App needs to be running on your phone if you want to Knock to unlock.







Knock to unlock works best if you from a bag or the pocket of a jacket.

of a tight pair of jeans, the Bluetooth signal might get distorted, causing the Knock to unlock to fail occasionally.



danalock App: Knock to unlock add-ons







Knock to unlock add-ons

Knock to unlock button you can choose if you want your smartphone to notify you whenever you are close to your lock.

